

## Working Of 'Phone for Blinds and ILLiterates'

### How To Dial A Number Stored In Dial-Card Fitted With Dial-Disc

**Step:1** Slide Dial-Mode Selection Switch (S-1) To Dial-Card Mode (D)

**Step:2** Use Card Selection Knob (K-1) To Select Desired Picture/Figure , Hence Telephone Number To Be Dialed

**Step:3** Press Redial Button 'R' Present On Telephone Key Pad

In This Way Telephone Number Stored In Selected Dial-Card Will Be Dialed

MOHD USMAN  
musmanq@rediffmail.com  
+91-9358484372

### How To Dial A Number Stored In Dial-Card Inserted Into Slot

**Step:1** Slide Dial-Mode Selection Switch (S-1) To Dial-Card Mode (D)

**Step:2** Pick A Desired Dial-Card ( Hence Number Stored In Card Is Selected)

**Step:3** Insert Selected Dial-Card Into Dial-Card Slot (DS-1)

**Step:4** Press Redial Button 'R' Present On Telephone Key Pad

In This Way Telephone Number Stored In Selected Dial-Card Will Be Dialed

**Note: When There Is A Dial-Card Inserted Into Dial-Card Slot Dial-Disc Will Be Disabled. Hence Number Stored In Dial-Card Inserted Into Dial-Card Slot Will Be Dialed**